

## HOSE BURST CHECK VALVE


HC970-...

List: HC970-1-Apr 2014

## **DESCRIPTION**


- ✓ Hose burst check valves for pipe mounting-HC970...
- ✓ Hose burst check valves prevent against an uncontrollable, accelerated movement of a loaded hydraulic actuator, when the back pressure is lost (as a result of damage or rupture in the pressurized line or pipe connections). The valve is screwed directly into the pressurized inlet port of the hydraulic actuator.

## **DIMENSIONS**



TYPE	G	L	L1	ØD	S1	S2
		mm				
HC970-1/4	G1/4"	25	12	8	2,5	5,5
HC970-3/8	G3/8"	28	14	9,5	2,5	5,5
HC970-1/2	G1/2"	34	16	13	3	7
HC970-3/4	G3/4"	39	22	16	3	7

## **APPLICATIONS**



#### **ORDERING CODE**

\*\*\* HC 970 Hose burst check valve

Modification

G1/4 -1/4

G3/8 -3/8

G1/2 -1/2

G3/4 -3/4


\*Other available threads: (metric) on request

-temperature

Mounting thread:

# **SYMBOL**

# detailed



## TECHNICAL DATA

Max. Pressure	330 Dai			
Rated flow - see characteristics				
Working liquid-hydraulic oils with characteristics:				
-viscosity	10400 cSt			
-degree of filtration	0.025 mm			


## **SETTING CURVES**

Measured at 50°C and 46cSt viscosity

Deviation from

the flow is 10%

May Proce



We reserve the right to change specifications without notice.

www.caproni.bg

HC970-1-Apr 2014

-20...+80°C